

Notes:

- 1. Allen key to be dialled all the way in. And one an a half turns outwards, this is the correct mix of cold and hot water.
- 2. Pump setting to be set to number 1 towards the left hand side on the constant setting, as indicated.
- **3A.** Siemens thermostat to activate the BCU to come on at 20 degrees, this is wired into terminal 3 and 1.
- **3B**. Siemens thermostat to be wired to turn the pump of one to temperatures reach 55o. This is wired to terminal 2 &2.
- **4.** Sensor Tee's one to be installed below the BCU on the flow line. Two thermostats required for the BCU.
- * It is recommended to operate the BCU with two thermostats, one activating the pump at a lower temperature and to shut off at a higher temperature.
- * Typical install requires only one thermostat to shut off at a higher temperature.

Pivot Stove and Heating

Hydronic Manual

Project Number N/A

Date 24/9/16

Drawn By Pivot Hydronics

Checked By Pivot Hydronics

A-8.00

REV -

Sheet Number

NOT TO SCALE

PIVOT STOVE & CONTROL HEATING SPECIALIST SINCE 1876

Hydronic Systems